

Set Q-U and P-U through FusionSolar APP



Huawei Technologies Co. Ltd.


Version	Created by	Date	Remarks
01	Huawei e84081311	01.02.2022	Q-U/P-U

The information in this document may contain predictive statements including, without limitation, statements regarding the future financial and operating results, future product portfolio, new technology, etc. There are a number of factors that could cause actual results and developments to differ materially from those expressed or implied in the predictive statements. Therefore, such information is provided for reference purpose only and constitutes neither an offer nor an acceptance. Huawei may change the information at any time without notice.

This document describes how to set the Q-U and P-U curve on the Huawei inverters with FusionSolar APP.


1. Connect on the inverter WiFi

Disable the data mobile from your phone and enable the WiFi. Choose from your WiFi list the SUN2000L-.....SN and connect with the default password **Changeme**




2. Login on inverter with FusionSolar APP


Open FusionSolar APP on your phone and from the main page choose **Setup-wizard**
Select the inverter from the list, if the inverter is not present choose **Connect** and scan the inverter QR code or insert manually the SN of the inverter.
Login with the default password **00000a**.




3. Set the P-U curve

From the main page select Parameters configuration → Expert → Feature parameters → enable Voltage rise suppression → select Voltage rise suppression P-U curve:






Set the Curve points to 2 and set the value U and P/Pn accordingly with the value provided by grid operator and **Submit**:




P-U for Australia region:


-Australia A:




-Australia B:



-Australia C:




- NZ:



4. Set the Q-U curve

From Expert settings menu → Feature parameters select Voltage rise suppression Q-U curve → set the Curve points to 4 → set the value U and Q/S accordingly with the value provided by grid operator and **Submit**:




Q-U for Australia region:

-Australia A:

Voltage rise suppression Q-U curve

Curve points - 4 +

	U(V) [184.0-312.8]	Q/S [-0.600-0.600]
1	207	0.44
2	220	0.000
3	240	0.000
4	258	-0.60



-Australia B:

Voltage rise suppression Q-U curve

Curve points - 4 +

	U(V) [184.0-312.8]	Q/S [-0.600-0.600]
1	205	(0.30)
2	220	0.000
3	235	0.000
4	255	--0.40




-Australia C:

Voltage rise suppression Q-U curve

Curve points - 4 +

	U(V) [184.0-312.8]	Q/S [-0.600-0.600]
1	215	(0.44)
2	230	0.000
3	240	0.000
4	255	--0.60



-NZ:

Voltage rise suppression Q-U curve

Curve points - 4 +

	U(V) [184.0-312.8]	Q/S [-0.600-0.600]
1	207	(0.60)
2	220	0.000
3	235	0.000
4	244	--0.60





If you have problem to set the P-U and Q-U curve please contact service team at eu_inverter_support@huawei.com.